

# sofamel

Product Technical Specifications

## Model RTE

### PVC SIGNS

#### Functionality and Features

SIGNAL PREREQUISITES with UV-resistant PVC paint.

#### Certificates

Recommendation **AMYS RA 1.1-10**

**UNE 1-115-85:** Colors and safety signs.

According to **UNE-EN ISO 7010:** Graphic symbols. Colors and safety signs. Registered safety signs (ISO 7010:2019) (Ratified by the Spanish Association for Standardization in May 2020).

And **UNE-EN 60417:** Graphic symbols to be used on equipment.

#### Dimensions

**RTE-42P:** 297 x 420 mm

**RTE-29P:** 210 x 297 mm

Previous requirements for H.V. ELECTRICAL INSTALLATION works

**DANGER** 

**BEFORE STARTING ANY WORK IN HIGH VOLTAGE INSTALLATIONS:**

- 1** **CUT** ALL POSSIBLE HIGH AND LOW VOLTAGE SUPPLY WHERE IT HAS TO BE OPERATED, USING, AT LEAST, HELMET, INSULATING STOOL, DIELECTRIC GLOVES AND PROTECTIVE GLASSES.
- 2** WHEN **USING** POLES, CLEAN THEM AND CONNECT IT TO EARTH IF NEEDED.
- 3** **BLOCK** THE CUTTING DEVICES, WHEN IT IS POSSIBLE.
- 4** **PLACE ON** THE CUTTING DEVICES CONTROL THE APPROPRIATE SAFETY SIGN.
- 5** **ALWAYS CHECK** VOLTAGE ABSENCE OF THE ELEMENTS WHERE WE NEED TO WORK OR THE ONES PLACED IN A DISTANCE THAT INVOLVES DANGER.
- 6** **PLACE** THE EARTHING AND SHORT CIRCUIT EQUIPMENTS IN ORDER TO INSULATE THE AREA.

IT IS TOTALLY FORBIDDEN TO GO INTO THE CELL BEFORE ENSURING THERE IS NO VOLTAGE PRESENCE INSIDE.

Datos sujetos a cambios  
October 28, 2022

Versión: R2-7.2 COM01

Thomas Alva Edison, 16-17 - Pol. Industrial Plans d'Arau - 08787 La Pobla de Claramunt (Barcelona) - Spain  
Tel. +34 93 808 79 80 - Info@sofamel.es  
[www.sofamel.com](http://www.sofamel.com)

© 2017 Sofamel SLU  
Todos los derechos reservados.

Las especificaciones están sujetas a cambios sin previo aviso.